



## Coupling element between two multi-leaf dampers type HVM

- Steel coupling element between two multi-leaf dampers
- For battery-mounted dampers
- To be ordered pre-mounted

### Order example

- **HVM**

Explanation

**HVM** = Coupling element for multi-leaf dampers